

The ProQ™ Eco Smoker is made from 90% recyclable materials and is an affordable option for cold smoking all types of food, such as fish, cheese, meat or vegetables.

PLEASE NOTE – The ProQ™ Eco Smoker is designed for use only with the ProQ™ Cold Smoke Generator. Using the box with any other brand or size may result in serious injury or damage to property. This product is **not compatible with the ProQ Artisan Cold Smoke Generator**. Please contact the point of sale if you have bought the wrong size. To set up your Eco Smoker, please follow the simple instructions below.

Assembly Instructions

Step 1

Locate and open out the inner box section, then push in the tabs (12 in total), as per Diagram 1. These are what the grills will rest upon.

Step 2

Assemble the outer box, then slide the inner box into it from the top (make sure the cut-out lines up with the small door in the bottom of the outer box).

Step 3

Assemble the remaining parts in the following order...

Base Tray - Sits in the bottom of the eco smoker box.

Drip Tray - Rests on the first set of tabs.

1st Grill - Rests on the handles of the Drip Tray.

2nd Grill - Rests on the second set of tabs.

3rd Grill - Rests on the top set of tabs.

Your ProQ™ Eco Smoker is now ready for use.

Do not use this unit indoors, it can create concentrations of carbon monoxide which is odourless and can be deadly if inhaled. Use in a well-ventilated area out of wind and rain.

Using your ProQ™ Eco Smoker

1. Put the base tray in place on the floor of the unit.
2. Put in the Drip Tray, which rests on the 1st set of tabs.
3. Place the 1st Grill so it rests on top of the Drip Tray Handles.
4. Place food onto the 1st Grill.
5. Place the 2nd Grill so it rests on the second set of tabs.
6. Place food onto the 2nd Grill.
7. Repeat step 5 and 6 for the remaining grill.
8. Follow the instructions for lighting the Cold Smoke Generator (This is best done outdoors in an area free of wind).
9. Once the dust in the Cold Smoke Generator is smouldering, **remove the candle** and gently slide the unit through the door in the bottom of the box. If the smoker does not fit through this door, you may have the wrong size cold smoke generator. **Do not use this** with the ProQ Eco Smoker Box, please contact your point of sale.
10. You're Smoking!

Please Note - This unit is designed for cold smoking only, for other methods and equipment go to www.proqsmokers.com

Please see www.proqsmokers.com for cold smoking recipes and tips

Diagram 1

